

RADIO FLYER

My First 2 in 1 Wagon

model #607

For ages 1-4 years. Max weight 35.0 lbs (15.9 kg).

適用年齡：1~4歲 最大承重：15.9KG

Thank you for your purchase. If you have any questions or comments, please visit the customer service section of our website:

謝謝您選購RADIO FLYER，若您有任何組裝上的問題及建議，請來電或到我們的網站上查看：



www.radioflyer.com.tw

www.goyouth.com.tw

或撥打客服專線:02-85112777 傳真:02-85110898

每周一至周五:10:00-18:00 info@goyouth.com.tw

Find us on **LINE** (ID:85112777)


Find us on **Facebook**



The Original Little Red Wagon™ - Since 1917


1

602517 (x1)



注意：禁止使用
電動工具組裝。


602513 (x2)




602514 (x1)



602511 (x4)



602507 (x4)



2 ⚠ WARNING:

ADULT ASSEMBLY REQUIRED.

Choking hazard to children under the age of 3 years – contains small parts prior to assembly. All fasteners should be fully tightened.

Please keep instructions for future reference.

⚠ 注意：

此商品需由成人組裝





組裝、使用時，請注意孩童安全

包裝內含小物件，應避免三歲以下兒童誤食。


拆裝及組裝時，請將小物件及塑膠包材放置在小朋友不易拿到的地方。所有固定組件如螺絲等請務必鎖緊。

請保留此說明書作為組裝時的參考


3




4



5




6




7


• Locking & unlocking handle:
• 鎖緊&鬆開把手:



• Wagon mode:
• 拖車模式:



• Walker mode:
• 學步車模式:



WARNING: TO AVOID SERIOUS INJURY:

- Continuous adult supervision is required.
- An adult should inspect the wagon periodically for loose, damaged or missing components.
- The maximum weight that this wagon is designed to carry is 35.0 lbs (15.9 kg).

PLEASE INSTRUCT THE USER TO FOLLOW THESE SAFE WAGON WALKING TIPS:

1. Never play with your wagon in the street.
2. Don't walk your wagon over large objects.
3. Don't walk your wagon up or down a steep hill.
4. Always wear shoes while using your wagon.
5. Do not use your wagon near steps, sloped driveways, hills, roadways, alleys, swimming pools or other bodies of water, cars or other motor vehicles.

CAUTION – PROPERLY DISPOSE OF ALL PACKING
INCLUDING ALL PLASTIC BAGS.



警告:

請詳細閱讀以免受傷

- 孩童玩耍時需成人陪同及監護。
- 成人應定期檢查車體組件是否鬆動或損壞。
- 車體最大承重為15.9KG(35.0 lbs)

請遵守下列安全使用守則：

1. 嚴禁在街道上使用本車。
2. 禁止將車體跨越大型物件。
3. 禁止使用本車上下斜坡。
4. 玩耍時請穿鞋
5. 禁止在以下地方玩耍:馬路街道、巷弄騎樓間、游泳池周圍、山林間、階梯、斜坡道及高速公路。

警告：組裝本車請丟棄或妥善收存所有外包裝及塑膠袋